

Engine Workshop Manual AJ with Variable Valve Timing

FOREWORD

This manual explains the disassembly, inspection, repair, and reassembly procedures for the above-indicated engine. In order to do these procedures safely, quickly, and correctly, you must first read this manual and any other relevant service materials carefully.

The information in this manual is current up to September, 2002. Any changes that occur after that time will not be reflected in this particular manual. Therefore, the contents of this manual may not exactly match the mechanism that you are currently servicing.

**Mazda North American Operations
U.S.A.**

CONTENTS

Title	Section
GENERAL INFORMATION	00
ENGINE	01

© 2002 Mazda North American Operations
PRINTED IN U.S.A., SEPTEMBER 2002
Form No. 1766-1U-02I
Part No. 9999-95-EAJV-03

GENERAL INFORMATION

00
SECTION

00-00

GENERAL INFORMATION . . . 00-00

00-00 GENERAL INFORMATION

HOW TO USE THIS MANUAL	00-00-2	Inspection During Removal,	
Range of Topics	00-00-2	Disassembly	00-00-6
Service Procedure	00-00-2	Arrangement of Parts	00-00-7
Symbols	00-00-4	Cleaning of Parts	00-00-7
Advisory Messages	00-00-4	Reassembly	00-00-8
UNITS	00-00-5	Adjustment	00-00-8
Conversion to SI Units		Rubber Parts and Tubing	00-00-8
(Système International d'Unités)	00-00-5	Hose Clamps	00-00-9
Rounding Off	00-00-5	Torque Formulas	00-00-9
Upper and Lower Limits	00-00-5	Vise	00-00-9
FUNDAMENTAL PROCEDURES	00-00-6	SST	00-00-10
Preparation of Tools and Measuring		ELECTRICAL SYSTEM	00-00-10
Equipment	00-00-6	Connectors	00-00-10
Special Service Tools	00-00-6	SAE STANDARDS	00-00-12
Disassembly	00-00-6	ABBREVIATIONS	00-00-13

GENERAL INFORMATION

HOW TO USE THIS MANUAL

B6U00000001101


Range of Topics

- This manual contains procedures for performing all required service operations. The procedures are divided into the following five basic operations:
 - i. Removal/Installation
 - ii. Disassembly/Assembly
 - iii. Replacement
 - iv. Inspection
 - v. Adjustment
- Simple operations which can be performed easily just by looking at the vehicle (i.e., removal/installation of parts, jacking, vehicle lifting, cleaning of parts and visual inspection) have been omitted.

Service Procedure

Inspection, adjustment

- Inspection and adjustment procedures are divided into steps. Important points regarding the location and contents of the procedures are explained in detail and shown in the illustrations.



X5U000MA0

GENERAL INFORMATION

00-00

Repair procedure

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together and describes visual part inspection. However, only removal/installation procedures that need to be performed methodically have written instructions.
2. Expendable parts, tightening torques and symbols for oil, grease, and sealant are shown in the overview illustration. In addition, symbols indicating parts requiring the use of special service tools or equivalent are also shown.
3. Procedural steps are numbered and the part that is the main point of that procedure is shown in the illustration with the corresponding number. Occasionally, there are important points or additional information concerning a procedure. Refer to this information when servicing the related part.

Procedure ↓ **FRONT UPPER LINK, FRONT UPPER LEADING LINK REMOVAL/INSTALLATION** — SHOWS SERVICE ITEM(S)

“Removal/Installation” Portion ①

1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the splash shield(s). (See 09-11-11 SPLASH SHIELD INSTALLATION.)
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.

“Inspection After Installation” Portion ②

5. Inspect the front wheel alignment and adjust it if necessary.

INDICATES RELEVANT REFERENCES THAT NEED TO BE FOLLOWED DURING INSTALLATION

SHOWS SPECIAL SERVICE TOOL (SST) FOR SERVICE OPERATION

SHOWS PROCEDURE ORDER FOR SERVICE

INSTALL THE PARTS BY PERFORMING STEPS 1-3 IN REVERSE ORDER

SHOWS APPLICATION POINTS OF GREASE, ETC.

SHOWS EXPENDABLE PARTS

SHOWS TIGHTENING TORQUE SPECIFICATIONS

SHOWS DETAILS

SHOWS REFERRAL NOTES FOR SERVICE

SHOWS TIGHTENING TORQUE UNITS

SHOWS REFERRAL NOTES FOR SERVICE

SHOWS SPECIAL SERVICE TOOL (SST) NO.

1	Split pin	5	Adjust cam bolt
2	Nut	6	Upper lateral link
3	Upper lateral link ball joint (See 02-13-6 Upper Lateral Link Ball Joint Removal Note)	7	Dust boot, clip (upper lateral link)
4	Cam nut, cam plate	8	Split pin
		9	Nut
		10	Upper leading link ball joint
		11	Upper leading link
		12	Dust boot (upper leading link)

Upper Lateral Link Ball Joint Removal Note

- Remove the ball joint using the SSTs.

49 T028 303

49 T028 304 UPPER LEADING LINK

49 T028 305 UPPER LATERAL LINK

KNUCKLE

N·m (kgf·m, ft·lb)

ZLU0000W109

GENERAL INFORMATION

Symbols

- There are eight symbols indicating oil, grease, fluids, sealant and **SST** or equivalent use. These symbols show application points or use of these materials during service.

Symbol	Meaning	Kind
	Apply oil	New, appropriate engine oil or gear oil
	Apply brake fluid	New, appropriate brake fluid
	Apply automatic transaxle/transmission fluid	New, appropriate automatic transaxle/transmission fluid
	Apply grease	Appropriate grease
	Apply sealant	Appropriate sealant
	Apply petroleum jelly	Appropriate petroleum jelly
	Replace part	O-ring, gasket, etc.
	Use SST or equivalent	Appropriate SST or equivalent

Advisory Messages

You'll find several **Warnings**, **Cautions**, **Notes**, **Specifications** and **Upper and Lower Limits** in this manual.

Warning

- A **Warning** indicates a situation in which serious injury or death could result if the warning is ignored.

Caution

- A **Caution** indicates a situation in which damage to the vehicle could result if the caution is ignored.

Note

- A **Note** provides added information that will help you to complete a particular procedure.

GENERAL INFORMATION

B6U00000002101

00-00

UNITS

Electric current	A (ampere)
Electric power	W (watt)
Electric resistance	ohm
Electric voltage	V (volt)
Length	mm (millimeter)
	in (inch)
Negative pressure	kPa (kilo pascal)
	mmHg (millimeters of mercury)
	inHg (inches of mercury)
Positive pressure	kPa (kilo pascal)
	kgf/cm ² (kilogram force per square centimeter)
	psi (pounds per square inch)
Number of revolutions	rpm (revolutions per minute)
Torque	N·m (Newton meter)
	kgf·m (kilogram force meter)
	kgf·cm (kilogram force centimeter)
	ft·lbf (foot pound force)
	in·lbf (inch pound force)
Volume	L (liter)
	US qt (U.S. quart)
	Imp qt (Imperial quart)
	ml (milliliter)
	cc (cubic centimeter)
	cu in (cubic inch)
Weight	fl oz (fluid ounce)
	g (gram)
	oz (ounce)

Conversion to SI Units (Système International d'Unités)

- All numerical values in this manual are based on SI units. Numbers shown in conventional units are converted from these values.

Rounding Off

- Converted values are rounded off to the same number of places as the SI unit value. For example, if the SI unit value is 17.2 and the value after conversion is 37.84, the converted value will be rounded off to 37.8.

Upper and Lower Limits

- When the data indicates upper and lower limits, the converted values are rounded down if the SI unit value is an upper limit and rounded up if the SI unit value is a lower limit. Therefore, converted values for the same SI unit value may differ after conversion. For example, consider 2.7 kgf/cm² in the following specifications:

210—260 kPa {2.1—2.7 kgf/cm², 30—38 psi}
270—310 kPa {2.7—3.2 kgf/cm², 39—45 psi}

- The actual converted values for 2.7 kgf/cm² are 264 kPa and 38.4 psi. In the first specification, 2.7 is used as an upper limit, so the converted values are rounded down to 260 and 38. In the second specification, 2.7 is used as a lower limit, so the converted values are rounded up to 270 and 39.


GENERAL INFORMATION

FUNDAMENTAL PROCEDURES

B6U00000004101

Preparation of Tools and Measuring Equipment


- Be sure that all necessary tools and measuring equipment are available before starting any work.



X5U000MAB

Special Service Tools


- Use special service tools or equivalent when they are required.



X5U000MAC

Disassembly


- If the disassembly procedure is complex requiring many parts to be disassembled, all parts should be disassembled in a way that will not affect their performance or external appearance and identified so reassembly can be performed easily and efficiently.



YMU000AA0

Inspection During Removal, Disassembly

- When removed, each part should be carefully inspected for malfunctioning, deformation, damage and other problems.




YMU000AA1

GENERAL INFORMATION

Arrangement of Parts

- All disassembled parts should be carefully arranged for reassembly.
- Be sure to separate or otherwise identify the parts to be replaced from those that will be reused.



YMU000AA2


00-00

Cleaning of Parts

- All parts to be reused should be carefully and thoroughly cleaned in the appropriate method.

Warning

- **Using compressed air can cause dirt and other particles to fly out causing injury to the eyes. Wear protective eye wear whenever using compressed air.**



WGIWXX0030J.


GENERAL INFORMATION

Reassembly


- Standard values, such as torques and certain adjustments, must be strictly observed in the reassembly of all parts. If removed, these parts should be replaced with new ones:
 - Oil seals
 - Gaskets
 - O-rings
 - Lockwashers
 - Cotter pins
 - Nylon nuts

Depending on location:

- Sealant and gaskets, or both, should be applied to specified locations. When sealant is applied, parts should be installed before sealant hardens to prevent leakage.
- Oil should be applied to the moving components of parts.
- Specified oil or grease should be applied at the prescribed locations (such as oil seals) before reassembly.




WGIWXX0031J



WGIWXX0032J

Adjustment


- Use suitable gauges and testers when making adjustments.



YMU000AA3

Rubber Parts and Tubing

- Prevent gasoline or oil from getting on rubber parts or tubing.




X5U000MAL

GENERAL INFORMATION

Hose Clamps

- When reinstalling, position the hose clamp in the original location on the hose and squeeze the clamp lightly with large pliers to ensure a good fit.



X5U000MAM

00-00


Torque Formulas

- When using a torque wrench-**SST** or equivalent combination, the written torque must be recalculated due to the extra length that the **SST** or equivalent adds to the torque wrench. Recalculate the torque using the following formulas. Choose the formula that applies to you.

Torque Unit	Formula
N·m	$N \cdot m \times [L / (L + A)]$
kgf·m	$kgf \cdot m \times [L / (L + A)]$
kgf·cm	$kgf \cdot cm \times [L / (L + A)]$
ft·lbf	$ft \cdot lbf \times [L / (L + A)]$
in·lbf	$in \cdot lbf \times [L / (L + A)]$

A : The length of the **SST** or equivalent past the torque wrench drive.


L : The length of the torque wrench.



X5U000MAN

Vise

- When using a vise, put protective plates in the jaws of the vise to prevent damage to parts.




X5U000MAP

GENERAL INFORMATION


SST

- Some global **SST** or equivalent are used as **SSTs** necessary for engine repair. Note that these **SSTs** are marked with global **SST** numbers.
- **SST** numbers are indicated in two ways, as shown in the following examples.
 - 01–60 section: Both MAZDA and global **SST** numbers are indicated for reference.
 - Except 01–60 section: Either only the MAZDA **SST** number or both the MAZDA **SST** and global **SST** numbers are shown.

Example (01-60 section)



Example (except 01-60 section)





ELECTRICAL SYSTEM

Connectors

Disconnecting connectors


- When disconnecting two connectors, grasp the connectors, not the wires.
- Connectors can be disconnected by pressing or pulling the lock lever as shown.



GENERAL INFORMATION

Locking connector

- When locking connectors, listen for a click indicating they are securely locked.



X5U000MAS


00-00

Inspection


- When a tester is used for inspecting continuity or measuring voltage, insert the tester probe from the wiring harness side.
- Inspect the terminals of waterproof connectors from the connector side since they cannot be accessed from the wiring harness side.

Caution

- To prevent damage to the terminal, wrap a thin wire around the lead before inserting into terminal.



WGIWXX0144E



WGIWXX0045E

GENERAL INFORMATION

B6U000000003101

SAE STANDARDS

- In accordance with new regulations, SAE (Society of Automotive Engineers) standard names and abbreviations are now used in this manual. The table below lists the names and abbreviations that have been used in Mazda manuals up to now and their SAE equivalents.

SAE Standard			SAE Standard		
Abbreviation	Name	Remark	Abbreviation	Name	Remark
AP	Accelerator Pedal		MAP	Manifold Absolute Pressure	
ACL	Air Cleaner		MAF sensor	Mass Air Flow Sensor	
A/C	Air Conditioning		MFL	Multiport Fuel Injection	
BARO	Barometric Pressure		OBD	On-board Diagnostic System	
B+	Battery Positive Voltage		OL	Open Loop	
CMP sensor	Camshaft Position Sensor		OC	Oxidation Catalytic Converter	
CAC	Charge Air Cooler		O2S	Oxygen Sensor	
CLS	Closed Loop System		PNP	Park/Neutral Position	
CTP	Closed Throttle Position		PSP	Power Steering Pressure	
CPP	Clutch Pedal Position		PCM	Powertrain Control Module	#3
CIS	Continuous Fuel Injection System		PAIR	Pulsed Secondary Air Injection	Pulsed injection
CKP sensor	Crankshaft Position Sensor		AIR	Secondary Air Injection	Injection with air pump
DLC	Data Link Connector		SAPV	Secondary Air Pulse Valve	
DTM	Diagnostic Test Mode	#1	SFI	Sequential Multiport Fuel Injection	
DTC	Diagnostic Test Code(s)		3GR	Third Gear	
DI	Distributor Ignition		TWC	Three Way Catalytic Converter	
DLI	Distributorless Ignition		TB	Throttle Body	
EI	Electronic Ignition	#2	TP sensor	Throttle Position Sensor	
ECT	Engine Coolant Temperature		TCC	Torque Converter Clutch	
EM	Engine Modification		TCM	Transmission (Transaxle) Control Module	
EVAP	Evaporative Emission		TR	Transmission (Transaxle) Range	
EGR	Exhaust Gas Recirculation		TC	Turbocharger	
FC	Fan Control		VSS	Vehicle Speed Sensor	
FF	Flexible Fuel		VR	Voltage Regulator	
4GR	Fourth Gear		VAF sensor	Volume Air Flow Sensor	
GEN	Generator		WU-TWC	Warm Up Three Way Catalytic Converter	#4
GND	Ground		WOT	Wide Open Throttle	
HO2S	Heated Oxygen Sensor	With heater			
IAC	Idle Air Control				
IAT	Intake Air Temperature				
KS	Knock Sensor				
MIL	Malfunction Indicator Lamp				

#1 : Diagnostic trouble codes depend on the diagnostic test mode.

#2 : Controlled by the PCM

#3 : Device that controls engine and powertrain

#4 : Directly connected to exhaust manifold

GENERAL INFORMATION

ABBREVIATIONS

B6U00000011101

00-00

CKP	Crankshaft position
EX	Exhaust
HLA	Hydraulic lash adjuster
IN	Intake
LH	Left hand
OCV	Oil control valve
P/S	Power steering
RH	Right hand
SST	Special service tool

ENGINE

01

SECTION

01-10

MECHANICAL 01-10
TECHNICAL DATA 01-50

SERVICE TOOLS 01-60

01-10 MECHANICAL

ENGINE OVERHAUL	
SERVICE WARNING	01-10-2
ENGINE MOUNTING	01-10-2
ENGINE DISMOUNTING	01-10-2
TIMING CHAIN DISASSEMBLY	01-10-3
Cylinder Head Cover	
Disassembly Note	01-10-4
Water Pump Drive Belt	
Disassembly Note	01-10-4
Water Pump Drive Pulley	
Disassembly Note	01-10-4
Camshaft Oil Seal Housing	
Disassembly Note	01-10-5
Oil Pan Disassembly Note	01-10-5
Crankshaft Pulley Disassembly Note	01-10-6
Engine Front Cover Disassembly Note	01-10-6
Chain Tensioner (RH)	
Disassembly Note	01-10-7
Camshaft Cap (RH)	
Disassembly Note	01-10-7
Variable Valve Timing Actuator	
Disassembly Note	01-10-8
Chain Tensioner (LH)	
Disassembly Note	01-10-8
Camshaft Cap (LH) Disassembly Note	01-10-8
CYLINDER HEAD DISASSEMBLY(I)	01-10-9
Water Pump Disassembly Note	01-10-10
Cylinder Head Disassembly Note	01-10-10
CYLINDER HEAD DISASSEMBLY(II)	01-10-11
Valve Keeper Disassembly Note	01-10-11
Valve Seal Disassembly Note	01-10-11
CYLINDER BLOCK DISASSEMBLY(I)	01-10-12
Oil Pump Disassembly Note	01-10-12
Flywheel (MTX), Drive Plate (ATX)	
Disassembly Note	01-10-13
CYLINDER BLOCK DISASSEMBLY(II)	01-10-13
Connecting Rod Cap	
Disassembly Note	01-10-14
Connecting Rod, Piston	
Disassembly Note	01-10-14
Piston Pin Disassembly Note	01-10-14
Lower Cylinder Block	
Disassembly Note	01-10-14
CYLINDER HEAD INSPECTION	01-10-15
VALVE, VALVE GUIDE INSPECTION	01-10-15
VALVE GUIDE REPLACEMENT	01-10-16
Valve Guide Removal	01-10-16
Valve Guide Installation	01-10-16

VALVE SEAT INSPECTION/REPAIR	01-10-16
VALVE SPRING INSPECTION	01-10-17
CAMSHAFT INSPECTION	01-10-18
CAMSHAFT OIL CLEARANCE	
INSPECTION	01-10-18
CAMSHAFT END PLAY INSPECTION	01-10-18
HYDRAULIC LASH ADJUSTER (HLA)	
INSPECTION	01-10-19
CYLINDER BLOCK INSPECTION	01-10-19
WATER INLET TUBE INSTALLATION	01-10-20
PISTON INSPECTION	01-10-20
PISTON CLEARANCE INSPECTION	01-10-20
PISTON RING CLEARANCE	
INSPECTION	01-10-21
PISTON PIN CLEARANCE	
INSPECTION	01-10-21
CRANKSHAFT INSPECTION	01-10-22
CRANKSHAFT OIL CLEARANCE	
INSPECTION/REPAIR	01-10-23
CRANKSHAFT END PLAY	
INSPECTION	01-10-24
CONNECTING ROD INSPECTION	01-10-25
CONNECTING ROD OIL CLEARANCE	
INSPECTION/REPAIR	01-10-25
CONNECTING ROD SIDE CLEARANCE	
INSPECTION	01-10-25
VARIABLE VALVE TIMING ACTUATOR	
INSPECTION	01-10-26
OIL CONTROL VALVE (OCV)	
INSPECTION	01-10-26
Coil Resistance Inspection	01-10-26
Spool Valve Operation Inspection	01-10-26
CYLINDER BLOCK ASSEMBLY(I)	01-10-28
Lower Cylinder Block Assembly Note	01-10-29
Piston Pin Assembly Note	01-10-31
Piston Ring Assembly Note	01-10-31
Piston, Connecting Rod	
Assembly Note	01-10-31
Connecting Rod Cap Assembly Note	01-10-32
CYLINDER BLOCK ASSEMBLY(II)	01-10-33
Flywheel (MTX), Drive Plate (ATX)	
Assembly Note	01-10-34
Oil Pump Assembly Note	01-10-34
Oil Baffle Assembly Note	01-10-34
Oil Strainer Assembly Note	01-10-34
CYLINDER HEAD ASSEMBLY(I)	01-10-35
Valve Seal Assembly Note	01-10-35
Valve Keeper Assembly Note	01-10-35

MECHANICAL

CYLINDER HEAD ASSEMBLY(II)	01-10-36
Cylinder Head Assembly Note	01-10-37
Water Pump Assembly Note	01-10-37
TIMING CHAIN ASSEMBLY	01-10-38
Variable Valve Timing Actuator Assembly Note	01-10-39
Camshaft (LH) Assembly Note	01-10-39
Chain Guide (LH, RH) Assembly Note .	01-10-40
Timing Chain (LH) Assembly Note	01-10-40
Camshaft (RH) Assembly Note	01-10-40
Timing Chain (RH) Assembly Note	01-10-41

Crankshaft Position (CKP) Sensor Pulse Wheel Assembly Note	01-10-42
Engine Front Cover Assembly Note . . .	01-10-42
Crankshaft Pulley Assembly Note	01-10-43
Oil Pan Assembly Note	01-10-44
Camshaft Oil Seal Housing Assembly Note	01-10-45
Water Pump Drive Pulley Assembly Note	01-10-45
Cylinder Head Cover Assembly Note . .	01-10-46

ENGINE OVERHAUL SERVICE WARNING

B6U011002000101

Warning

- Continuous exposure to USED engine oil has caused skin cancer in laboratory mice. Protect your skin by washing with soap and water immediately after this work.


ENGINE MOUNTING

B6U011002000102

1. Install the **SST** (engine hanger) to the cylinder block holes as indicated in the figure, and tighten the **SSTs** (bolts).
2. Mount the engine on the **SST** (engine stand).
3. Drain the engine oil into a container.
4. Inspect the seal rubber of the oil pan drain plug and make sure there are no cracks or damage.
 - If necessary, replace the oil pan drain plug.
5. Clean the flange surface (seal rubber) of the drain plug, then install the plug.

Tightening torque

22—30 N·m {2.2—3.1 kgf·m, 16—22 ft·lbf}



YMU110ACA

ENGINE DISMOUNTING

B6U011002000103

1. Dismount in the reverse order of mounting.


MECHANICAL

TIMING CHAIN DISASSEMBLY

B6U011012201101

01-10

1. Disassemble in the order indicated in the table.



N·m (kgf-m, ft-lbf)

B6U2216E002


1	Spark plug
2	Engine hanger
3	Oil level gauge, pipe
4	Cylinder head cover (See 01-10-4 Cylinder Head Cover Disassembly Note)
5	Water pump drive belt (See 01-10-4 Water Pump Drive Belt Disassembly Note)
6	Water pump drive pulley (See 01-10-4 Water Pump Drive Pulley Disassembly Note)
7	Camshaft oil seal housing (See 01-10-5 Camshaft Oil Seal Housing Disassembly Note)
8	Oil pan (See 01-10-5 Oil Pan Disassembly Note)
9	Auto tensioner
10	Crankshaft pulley (See 01-10-6 Crankshaft Pulley Disassembly Note)
11	Engine front cover (See 01-10-6 Engine Front Cover Disassembly Note)
12	CKP sensor pulse wheel
13	Chain tensioner (RH) (See 01-10-7 Chain Tensioner (RH) Disassembly Note)
14	Tensioner arm (RH)

15	Timing chain (RH)
16	Oil control valve (OCV)
17	Chain guide (RH)
18	Camshaft cap (RH) (See 01-10-7 Camshaft Cap (RH) Disassembly Note)
19	Camshaft (RH)
20	Variable valve timing actuator (RH) (See 01-10-8 Variable Valve Timing Actuator Disassembly Note)
21	Rocker arm (RH)
22	Chain tensioner (LH) (See 01-10-8 Chain Tensioner (LH) Disassembly Note)
23	Tensioner arm (LH)
24	Timing chain (LH)
25	Crankshaft timing sprocket
26	Oil control valve (OCV)
27	Chain guide (LH)
28	Camshaft cap (LH) (See 01-10-8 Camshaft Cap (LH) Disassembly Note)
29	Camshaft (LH)
30	Variable valve timing actuator (LH) (See 01-10-8 Variable Valve Timing Actuator Disassembly Note)
31	Rocker arm (LH)

MECHANICAL

Cylinder Head Cover Disassembly Note


1. Remove the cylinder head cover bolts in the order indicated in the figure.



B6U2215E102

Water Pump Drive Belt Disassembly Note


1. Rotate the belt tensioner counterclockwise to release the drive belt tension and remove the belt.



B6U2210W101

Water Pump Drive Pulley Disassembly Note


1. Replace part A of the **SST** [303-009 (49 UN30 3009)] with the **SST** [303-457 (49 UN30 3457)].



YMU110ACB


MECHANICAL

2. Remove the water pump pulley using the SSTs.




Camshaft Oil Seal Housing Disassembly Note

1. Remove the oil seal using a screwdriver.



Oil Pan Disassembly Note


1. Remove the oil pan bolts and studs in the order indicated in the figure.



MECHANICAL


Crankshaft Pulley Disassembly Note

1. Hold the the flywheel (MTX) or the drive plate (ATX) using the **SST**.
2. Remove the crankshaft pulley lock bolt.



YMU110AA6


3. Remove the crankshaft pulley using the **SST** and three bolts (**M8 × 1.25 × 45**).



YMU110AA7


Engine Front Cover Disassembly Note

1. Remove the engine front cover bolts and studs in the order indicated in the figure.



B6U2215W117


2. Remove the oil seal using a screwdriver.



YMU110AE7


Chain Tensioner (RH) Disassembly Note

1. Before removing chain tensioner (RH), turn the crankshaft clockwise to position the crankshaft keyway in the **3 o'clock** position. (camshafts (RH) are in the neutral position.)
2. Hold the timing chain tensioner ratchet lock mechanism away from the ratchet stem with a thin screwdriver.
3. Slowly press the tensioner piston.



YMU110WAL

4. Hold the tensioner piston with a **1.5 mm {0.06 in}** wire or paper clip.



TENSIONER PISTON

YMU110ACC

Camshaft Cap (RH) Disassembly Note

1. Before removing the camshaft cap, inspect the following.
 - (1) Camshaft end play (See 01-10-18 CAMSHAFT END PLAY INSPECTION.)
 - (2) Camshaft journal oil clearance (See 01-10-18 CAMSHAFT OIL CLEARANCE INSPECTION.)


Caution

- Remove the camshaft bearing thrust caps 1R and 5R first. Do not loosen any of the other bolts until the thrust caps are removed, or damage to the thrust caps may occur.

Note

- The camshaft bearing caps are numbered to make sure they are assembled in their original positions. When removed, keep the bearing caps with the cylinder head from where they were removed. Do not mix the caps.

2. Remove the camshaft cap bolts in the order indicated in the figure, loosening in several passes.



B6U2215W112

MECHANICAL

Variable Valve Timing Actuator Disassembly Note


Caution

- The variable valve timing actuator cannot be disassembled because it is a precision unit.

Note

- The variable valve timing actuator camshaft sprocket is integrated with the variable valve timing actuator and cannot be disassembled.


1. Secure the camshaft sprocket in a vise using the **SST**.
2. Loosen the variable valve timing actuator tightening bolt.
3. Remove the variable valve timing actuator.



B6U2225W012

Chain Tensioner (LH) Disassembly Note

1. Before removing chain tensioner (LH), turn the crankshaft clockwise **1 and 2/3 turns** to position the crankshaft keyway in the **11 o'clock** position. (camshafts (LH) are in the neutral position.)
2. Press and hold the tensioner piston by following Step 4 to 6 in Chain Tensioner (RH) Disassembly Note. (See 01-10-7 Chain Tensioner (RH) Disassembly Note.)



YMU110AAD

Camshaft Cap (LH) Disassembly Note

1. Before removing the camshaft cap, inspect the following.
 - (1) Camshaft end play (See 01-10-18 CAMSHAFT END PLAY INSPECTION.)
 - (2) Camshaft journal oil clearance (See 01-10-18 CAMSHAFT OIL CLEARANCE INSPECTION.)

Caution

- Remove the camshaft bearing thrust caps 1L and 6L first. Do not loosen any of the other bolts until the thrust caps are removed, or damage to the thrust caps may occur.


Note

- The camshaft bearing caps are numbered to make sure they are reassembled in their original position. When removed, keep the bearing caps with the cylinder head from where they were removed. Do not mix the caps.

MECHANICAL

01-10

2. Remove the camshaft cap bolts in the order indicated in the figure, loosening in several passes.




B6U2215W113

CYLINDER HEAD DISASSEMBLY(I)

B6U011010100101

1. Disassemble in the order indicated in the table.



B6U2224E010


1	Water pump drive belt tensioner
2	Water pump (See 01-10-10 Water Pump Disassembly Note)
3	Water bypass tube

4	HLA
5	Cylinder head (See 01-10-10 Cylinder Head Disassembly Note)
6	Cylinder head gasket

MECHANICAL

Water Pump Disassembly Note


1. Remove the water pump mounting bolts as shown.



YMU110ACD

Cylinder Head Disassembly Note

1. Remove the cylinder head bolts in the order indicated in the figure, loosening in several passes.



B6U2224E003


MECHANICAL

CYLINDER HEAD DISASSEMBLY(II)

1. Disassemble in the order indicated in the table.

1	Valve keeper (See 01-10-11 Valve Keeper Disassembly Note)
2	Upper valve spring seat
3	Valve spring
4	Valve
5	Valve seal (See 01-10-11 Valve Seal Disassembly Note)

B6U011010100102




01-10

B6U2224E011

Valve Keeper Disassembly Note


1. Remove the valve keeper using the SSTs.



YMU110AAK

Valve Seal Disassembly Note

1. Remove the valve seal using the SST.




YMU110AAL

MECHANICAL

CYLINDER BLOCK DISASSEMBLY(I)

B6U011010300101

1. Disassemble in the order indicated in the table.




B6U2224E001

1	Plate
2	Oil strainer
3	Oil baffle
4	Oil pump (See 01-10-12 Oil Pump Disassembly Note)

5	Flywheel (MTX), Drive plate (ATX) (See 01-10-13 Flywheel (MTX), Drive Plate (ATX) Disassembly Note)
6	End plate

Oil Pump Disassembly Note

1. Remove the bolts in the order indicated in the figure.




YMU110AAN

MECHANICAL

Flywheel (MTX), Drive Plate (ATX) Disassembly Note

1. Hold the flywheel (MTX) or the drive plate (ATX) using the SST.
2. Remove the bolts, loosening in several passes.




YMU110AAP

01-10

CYLINDER BLOCK DISASSEMBLY(II)

B6U011010300102

1. Disassemble in the order indicated in the table.



YMU110AAQ

1	Connecting rod cap (See 01-10-14 Connecting Rod Cap Disassembly Note)
2	Connecting rod bearing
3	Connecting rod, piston (See 01-10-14 Connecting Rod, Piston Disassembly Note)
4	Piston ring
5	Snap ring
6	Piston pin (See 01-10-14 Piston Pin Disassembly Note)

7	Connecting rod
8	Piston
9	Lower cylinder block (See 01-10-14 Lower Cylinder Block Disassembly Note)
10	Lower main bearing, thrust bearing
11	Crankshaft
12	Upper main bearing, thrust bearing
13	Upper cylinder block

MECHANICAL

Connecting Rod Cap Disassembly Note


1. Before removing the connecting rod cap, inspect the connecting rod side clearance. (See 01-10-25 CONNECTING ROD SIDE CLEARANCE INSPECTION.)
2. Remove the connecting rod bolt from the connecting rod cap by tapping the bolt with a plastic hammer.

Connecting Rod, Piston Disassembly Note

1. Before removing the connecting rod and piston, inspect the connecting rod oil clearance. (See 01-10-25 CONNECTING ROD OIL CLEARANCE INSPECTION/REPAIR.)

Piston Pin Disassembly Note


1. Remove the piston pin using the SST.



YMU110AAR

Lower Cylinder Block Disassembly Note

1. Before removing the lower cylinder block, inspect the crankshaft end play. (See 01-10-24 CRANKSHAFT END PLAY INSPECTION.)
2. Remove the lower cylinder block bolts in the order indicated in the figure in, loosening several passes.




AMU2224E002

CYLINDER HEAD INSPECTION

B6U011010100103

1. Carry out color contrast penetration examination on the cylinder head surface.
 - Replace the cylinder head if necessary.
2. Inspect for the following and replace if necessary.
 - (1) Camshaft end play (See 01-10-18 CAMSHAFT END PLAY INSPECTION.)
 - (2) Camshaft journal oil clearance (See 01-10-18 CAMSHAFT OIL CLEARANCE INSPECTION.)
3. Measure the cylinder head for distortion in the six directions as indicated in the figure.
 - If the cylinder head distortion exceeds the maximum, replace the cylinder head. Do not attempt to repair the cylinder head by milling or grinding.



YMU110AD3


01-10

Maximum distortion
0.08 mm {0.0031 in}

VALVE, VALVE GUIDE INSPECTION

1. Measure the stem diameter of each valve in X and Y directions at the three points (A, B, and C) as indicated in the figure.
 - If not as specified, replace the valve.


Standard diameter
IN: 5.975—5.995 mm {0.2352—0.2360 in}
EX: 5.950—5.970 mm {0.2343—0.2350 in}



B6U011012111101

YMU110AD3


2. Measure the inner diameter of each valve guide in X and Y directions at the three points (A, B, and C) as indicated in the figure.



YMU110AD4

3. Calculate the valve stem to guide clearance by subtracting the outer diameter of the valve stem from the inner diameter of the corresponding valve guide.
 - If not as specified, replace the valve and/or the valve guide.

Standard clearance
IN: 0.020—0.069 mm {0.0008—0.0027 in}
EX: 0.045—0.094 mm {0.0018—0.0037 in}




B6U2224E316

VALVE GUIDE REPLACEMENT

B6U011010280101

Valve Guide Removal

1. Remove the valve guide from the combustion chamber side using the **SST**.



YMU110AD6

Valve Guide Installation


1. Assemble the **SSTs** so that depth **L** is as specified.

Depth L

IN: 13.4—14.2 mm {0.528—0.559 in}

EX: 13.4—14.2 mm {0.528—0.559 in}

2. Tap the valve guide in from the side opposite the combustion chamber until the **SSTs** contact the cylinder head.




YBR2224A040

3. Verify that the valve guide projection height is within the specification.

Standard height

IN: 13.4—14.2 mm {0.528—0.559 in}

EX: 13.4—14.2 mm {0.528—0.559 in}



YBR2224A041

VALVE SEAT INSPECTION/REPAIR

B6U011010102101


1. Measure the seat contact width.

- If not as specified, resurface the valve seat using a **45°** valve seat cutter and/or resurface the valve face.

Standard width


IN: 1.1—1.4 mm {0.043—0.055 in}

EX: 1.4—1.7 mm {0.056—0.066 in}



YMU110AD9

2. Verify that the valve seating position is at the center of the valve face.
 - If the seating position is too high, correct the valve seat using a **70°** cutter, and then **45°** cutter.
 - If the seating position is too low, correct the valve seat using **30°** cutter, and then **45°** cutter.



YMU110ADA

VALVE SPRING INSPECTION

1. Apply pressing force to the pressure spring and inspect the spring height.
 - If not as specified, replace the valve spring.


Pressing force

680 N {69.3 kgf, 152 lbf}

Standard height

30.19 mm {1.189 in}

B6U011012125101




YMU110ADC

2. Measure the amount of off-square on the valve spring.
 - If not as specified, replace the valve spring.

Valve spring maximum off-square

1% (0.468 mm {0.00184 in})



YMU110ADD

MECHANICAL

CAMSHAFT INSPECTION


B6U011012420101

1. Measure the cam lobe height at the two points as indicated in the figure to calculate the gap between X and Y.
 - If not as specified, replace the camshaft.

Standard height

IN: 4.79 mm {0.189 in}

EX: 4.79 mm {0.189 in}




YMU110ADF

2. Measure the journal diameters in X and Y directions at the two points (A and B) as indicated in the figure.
 - If not as specified, replace the camshaft.

Standard diameter

26.936—26.962 mm {1.0604—1.0615 in}



YMU110ADG

CAMSHAFT OIL CLEARANCE INSPECTION

B6U011012420102


1. Position plastigage atop the journals in the axial direction.
2. Install the camshaft cap. (See 01–10–40 Timing Chain (LH) Assembly Note.) (See 01–10–41 Timing Chain (RH) Assembly Note.)
3. Remove the camshaft cap. (See 01–10–7 Camshaft Cap (RH) Disassembly Note.) (See 01–10–8 Camshaft Cap (LH) Disassembly Note.)
4. Measure the oil clearance.
 - If the oil clearance exceeds the maximum clearance, replace the cylinder head.

Standard clearance

0.025—0.076 mm {0.0010—0.0029 in}

Maximum clearance

0.121 mm {0.00476 in}



YMU110ADH

CAMSHAFT END PLAY INSPECTION

B6U011012420103

1. Measure the camshaft end play.
 - If the camshaft end play exceeds the maximum end play, replace the cylinder head or camshaft.


Standard end play

0.025—0.165 mm {0.0010—0.0064 in}

Maximum end play

0.190 mm {0.00748 in}

2. Remove the camshaft cap. (See 01–10–7 Camshaft Cap (RH) Disassembly Note.) (See 01–10–8 Camshaft Cap (LH) Disassembly Note.)



B6U2217E001

HYDRAULIC LASH ADJUSTER (HLA) INSPECTION

B6U011012100101

01-10

1. Measure the diameter of each HLA bore.

Standard diameter

16.018—16.057 mm {0.63063—0.63216 in}

2. Measure the diameter of each HLA.

Standard diameter

15.988—16.000 mm {0.62945—0.62992 in}

3. Calculate the clearance between the HLA and the related HLA bores.

- If the clearance exceeds the maximum clearance, replace the cylinder head or the HLA.

Standard clearance

0.018—0.069 mm {0.0008—0.0027 in}

Maximum clearance


0.16 mm {0.0063 in}

CYLINDER BLOCK INSPECTION

1. Measure the distortion of the cylinder block top surface in the six directions as indicated in the figure.
 - If not as specified, replace the cylinder block.

Cylinder block maximum distortion

0.08 mm {0.0031 in}



YMU110AD0

2. Measure the cylinder bores in X and Y directions at **50 mm {2.0 in}** below the top surface.
 - If the difference between measurements A and C exceeds the maximum taper, replace the cylinder block.
 - If the difference between measurements X and Y exceeds the maximum distortion, replace the cylinder block.

Cylinder bore


89.000—89.030 mm {3.5039—3.5051 in}

Maximum taper

0.020 mm {0.00079 in}

Off-round

0.020 mm {0.00079 in}



YMU110ADL

WATER INLET TUBE INSTALLATION

B6U011002000104

Note


- When replacing a cylinder block that has no water inlet tube.

1. Apply silicone sealant to the water inlet tube as indicated in the figure.

Thickness

2.0 mm {0.079 in}

2. Install the water inlet tube using the **SST**.




YMU110ADM

PISTON INSPECTION

1. Measure the outer diameter of each piston at a right angle (90°) to the piston pin, **42.6 mm {1.68 in}** below the top of the piston.
 - If the piston diameter is below the standard diameter, replace the piston.

Piston diameter

88.990—89.030 mm {3.5036—3.5051 in}



B6U011011010101

AMU2224E003

PISTON CLEARANCE INSPECTION

1. Measure the piston-to-cylinder clearance.
 - If not as specified, replace the piston or the cylinder block.
 - If the piston is replaced, the piston rings must also be replaced.

Standard clearance

0.012—0.022 mm {0.0004—0.0008 in}

B6U011011010102

PISTON RING CLEARANCE INSPECTION

1. Measure the piston ring-to-ring groove clearance around the entire circumference.
 - If the piston ring-to-ring groove clearance exceeds the maximum clearance, replace the piston and piston ring.

Standard clearance

Top: 0.040—0.075 mm {0.0016—0.0029 in}

Second: 0.040—0.085 mm {0.0016—0.0033 in}

Maximum clearance

0.10 mm {0.0039 in}

2. Insert the piston ring into the cylinder by hand and use the piston to push it to the bottom of the ring travel.
3. Measure each piston ring end gap with a feeler gauge.
 - If the piston ring end gap exceeds the maximum end gap, replace the piston ring.

Standard end gap

Top: 0.10—0.25 mm {0.004—0.009 in}

Second: 0.27—0.42 mm {0.011—0.016 in}

Oil (side rail): 0.15—0.65 mm {0.006—0.025 in}


Maximum end gap

Top: 0.50 mm {0.019 in}


Second: 0.65 mm {0.025 in}

Oil (side rail): 0.90 mm {0.035 in}

B6U011011010103



YMU110ADP



YMU110ADQ

01-10


PISTON PIN CLEARANCE INSPECTION

1. Measure each piston pin bore diameter in X and Y directions at the four points (A, B, C and D) as indicated in the figure.

Standard diameter

21.008—21.012 mm {0.82709—0.82724 in}

B6U011011010104




YMU110ADR

2. Measure each connecting rod small end inner diameter in X and Y directions as indicated in the figure.

Standard diameter

21.017—21.031 mm {0.82744—0.82799 in}



YMU110ADS

MECHANICAL

- Measure each piston pin diameter in X and Y directions at the four points (A, B, C and D) as indicated in the figure.

Standard diameter

21.011—21.013 mm {0.82721—0.82728 in}

- Calculate the piston pin-to-piston pin bore clearance.
 - If not as specified, replace the piston and/or piston pin.

Standard clearance

-0.005—0.001 mm {-0.00019—0.00003 in}


- Calculate small end-to-piston pin clearance of the connecting rod.
 - If small end-to-piston pin clearance of the connecting rod exceeds the maximum clearance, replace the connecting rod or piston pin.

Standard clearance

0.004—0.020 mm {0.00016—0.00078 in}

Maximum clearance

0.035 mm {0.0013 in}



YMU110ADT


CRANKSHAFT INSPECTION

- Measure the crankshaft runout.
 - If the crankshaft runout exceeds the maximum runout, replace the crankshaft.

Maximum runout

0.05 mm {0.0019 in}

B6U011011301101




YMU110ADU

- Measure the journal diameter in X and Y directions at the two points (A and B) as indicated in the figure.
 - If not as specified, replace the crankshaft or grind the journal and install the undersize bearing.

Main journal

mm {in}

Bearing size	Standard diameter
Standard	62.968—62.992 {2.4791—2.4799}
0.25 {0.01} undersize	62.718—62.742 {2.4693—2.4701}



YMU110ADV

Crank pin

mm {in}

Bearing size	Standard diameter
Standard	49.970—49.990 {1.9674—1.9681}
0.02 {0.0008} undersize	49.950—49.970 {1.9666—1.9673}
0.05 {0.0020} undersize	49.920—49.940 {1.9654—1.9661}
0.25 {0.01} undersize	49.720—49.740 {1.9575—1.9582}

CRANKSHAFT OIL CLEARANCE INSPECTION/REPAIR

B6U011011301102

Caution


- Because the bolts are pliant bolts, they cannot reused. Use new bolts for inspection. The bolts may be reused for assembly.

1. Install the upper main bearing and crankshaft.
2. Position a plastigage atop the journals in the axial direction.
3. Install the lower mainbearing and lower cylinder block, and tighten the bolts in the order indicated in the figure.

Tightening torque

37—43 N·m {3.7—4.4kgf·m, 27—31 ft·lbf}

4. Tighten the bolts by turning each **85° — 95°** in the sequence as indicated in the figure.
5. Loosen the bolts in the reverse order of tightening.



YMU110ADW


6. Measure the main journal oil clearance.
 - If the clearance exceeds the maximum, replace the main bearing using the main bearing selection table or grind the main journal and install the undersize bearings so that the specified oil clearance is obtained.

Standard clearance

0.025—0.045 mm {0.0010—0.0017 in}

Maximum clearance

0.050 mm {0.0019 in}



YMU110ADX

mm {in}

Bearing size	Grade	Bearing thickness	
		Upper: No.1,2,3,4 Lower: No.1,2,3	Lower: No.4
Standard	1	2.494—2.500 {0.09819— 0.09842}	2.492—2.498 {0.09812— 0.09834}
	2	2.498—2.504 {0.09835— 0.09858}	2.496—2.502 {0.09827— 0.09850}
	3	2.502—2.508 {0.09851— 0.09873}	2.5000—2.5006 {0.09843— 0.09844}
0.25 {0.01} undersize	—	2.623—2.629 {0.10327— 0.10350}	2.621—2.627 {0.10319— 0.10342}


MECHANICAL

Main bearing selection table

		BLOCK CODE																						
		98	99	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20
CRANKSHAFT CODE	92	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2
	91	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2
	90	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2
	89	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2
	88	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2
	87	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2
	86	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2
	85	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2
	84	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	3
	83	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	3
	82	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	3
	81	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	3
	80	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	3
	79	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	3
	78	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	3
	77	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	3
	76	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3
	75	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3
	74	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3
	73	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3
	72	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3
71	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	
70	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	
69	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	
68	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	

B6U2224E119

Example of main bearing selection




YMU110AE6

CRANKSHAFT END PLAY INSPECTION

B6U011011301103

1. Measure the crankshaft end play.
 - If not as specified, replace the thrust bearing and No.4 lower main bearing or crankshaft so that the specified end play is obtained.

Standard end play
0.110—0.232 mm {0.00434—0.00913 in}



YMU110ADY

CONNECTING ROD INSPECTION

1. Measure each connecting rod for bending and distortion.
 - If not as specified, replace the connecting rod.

Bending


0.038 mm {0.0014 in}max./25 mm {0.98 in}

Distortion

0.050 mm {0.0019 in}max./25 mm {0.98 in}

Center-to-center distance

138.06—138.14 mm {5.4355—5.4385 in}



01-10


CONNECTING ROD OIL CLEARANCE INSPECTION/REPAIR

B6U0110112111102

Caution

- Because the bolts are pliant bolts, they cannot reused. Use new bolts for inspection. The bolts may be reused for assembly.

1. Position plastigage atop the journals in the axial direction.
2. Install the connecting rod bearing and connecting rod cap. (See 01-10-32 Connecting Rod Cap Assembly Note.)
3. Remove the connecting rod cap.
4. Measure the connecting rod oil clearance.
 - If not as specified, replace the connecting rod bearing or grind the crankpin and use undersize bearings so that the specified clearance is obtained.



Standard clearance

0.028—0.066 mm {0.0012—0.0025 in}

mm {in}

Bearing size	Bearing thickness
Standard	1.500—1.506 {0.0591—0.0593}
0.02 {0.0008} undersize	1.510—1.516 {0.0595—0.0596}
0.05 {0.002} undersize	1.525—1.531 {0.0601—0.0602}
0.25 {0.01} undersize	1.625—1.631 {0.0640—0.0642}

CONNECTING ROD SIDE CLEARANCE INSPECTION


1. Measure the connecting rod large end side clearance.
 - If the connecting rod side clearance exceeds the maximum clearance, replace the connecting rod and cap.

Standard clearance

0.10—0.30 mm {0.004—0.011 in}

Maximum clearance

0.35 mm {0.013 in}




VARIABLE VALVE TIMING ACTUATOR INSPECTION

B6U011000142101

Caution

- The variable valve timing actuator cannot be disassembled because it is a precision unit.

1. Confirm that the key groove of the rotor and the timing mark of the sprocket at the variable valve timing actuator are aligned and fitted.
 - If the timing mark and the key groove are not aligned, rotate the rotor toward the bulb timing retard position by hand until they are in place.
 - If the rotor and sprocket are not secured even though their timing mark and the key groove are aligned, replace the variable valve timing actuator.



B6U2224E002

OIL CONTROL VALVE (OCV) INSPECTION

B6U011014420101


Coil Resistance Inspection

1. Disconnect the negative battery cable.
2. Disconnect the oil control valve (OCV) connector.
3. Measure the resistance between terminals A and B using an ohmmeter.
 - If not as specified, replace the oil control valve (OCV).

Specification

7.05—7.95 ohms


4. Connect the oil control valve (OCV) connector.



A6A2226W101

Spool Valve Operation Inspection


1. Disconnect the negative battery cable.
2. Remove the oil control valve (OCV).
3. Verify that the spool valve in the oil control valve (OCV) is in the maximum valve timing retard position as indicated in the figure.
 - If not as specified, replace the oil control valve (OCV).
4. Verify that the battery is fully charged.
 - If not as specified, recharge the battery.



B6U2424E001

MECHANICAL

5. Apply battery positive voltage between the oil control valve (OCV) terminals and verify that the spool valve operates and moves to the maximum valve timing advance position.




A6A2226W101

- If not as specified, replace the oil control valve (OCV).

Note

- When applying battery positive voltage between the oil control valve (OCV) terminals, the connection can be either of the following:
 - Positive battery cable to terminal A, negative battery cable to terminal B
 - Positive battery cable to terminal B, negative battery cable to terminal A



B6U2424E002


6. Stop applying battery positive voltage and verify that the spool valve returns to the maximum valve timing retard position.
 - If not as specified, replace the oil control valve (OCV).

MECHANICAL

CYLINDER BLOCK ASSEMBLY(I)

B6U011010300104

1. Assemble in the order indicated in the table.



YMU110AAT

1	Upper cylinder block
2	Upper main bearing, thrust bearing
3	Crankshaft
4	Lower main bearing, thrust bearing
5	Lower cylinder block (See 01-10-29 Lower Cylinder Block Assembly Note)
6	Piston
7	Connecting rod
8	Piston pin (See 01-10-31 Piston Pin Assembly Note)


9	Snap ring
10	Piston ring (See 01-10-31 Piston Ring Assembly Note)
11	Piston, connecting rod (See 01-10-31 Piston, Connecting Rod Assembly Note)
12	Connecting rod bearing
13	Connecting rod cap (See 01-10-32 Connecting Rod Cap Assembly Note)

Lower Cylinder Block Assembly Note

1. Apply a continuous bead of silicone sealant to the upper cylinder block as indicated in the figure.

Caution

- Because bolts 1—16 are pliant bolts, they cannot be reused. Replace bolts 1—8 with new bolts and use bolts 9—16 installed during inspection when assembling the lower cylinder block.






YMU110AAU


01-10

2. Install the lower cylinder block bolts in the order indicated in the figure.

Tightening torque

3.0—5.0 N·m {30—51 kgf·cm, 27—44 in·lbf}

Hole No.	Bolt	Description
18, 19, 20, 21, 22		M8×1.25×79.3 bolt
1, 2, 3, 4, 17		M8×1.25×96 bolt
13, 14, 15, 16		M10×1.5×106.5 bolt
5, 6, 7, 8		M8×1.25×96 stud/M6×1.0×18
9, 10, 11, 12		M10×1.5×106.8/ M8×1.25×21.5 stud




AMU2224E004

3. Push crankshaft forward and then rearward to seat the crankshaft thrust washer.

MECHANICAL


4. Tighten the lower cylinder block bolts in the order indicated in the figure in four steps.

- (1) Bolts 1-8: tighten to **22—28 N·m {2.2—2.9 kgf·m, 16—20 ft·lbf}**.
- (2) Bolts 9-16: tighten to **37—43 N·m {3.7—4.4 kgf·m, 27—31 ft·lbf}**.
- (3) Bolts 1-16: tighten **85°—95°**.
- (4) Bolts 17-22: tighten to **20—30 N·m {2.1—3.0 kgf·m, 15—22 ft·lbf}**.
- (5) Verify that the crankshaft rotates freely.




AMU2224E004

5. Assemble rear oil seal with part A of the **SST** [303-178 (49 UN01 070)] and the **SST** [303-384 (49 UN30 3384)].




YMU110ACJ

- (1) Install the studs of the **SST** as indicated in the figure.
- (2) Apply clean engine oil to the oil seal.
- (3) Push the oil seal slightly in by hand.



YMU110ACK


(4) Install part A of the **SST** [303-178 (49 UN01 070)] and compress the oil seal with the nuts of the **SST** [303-384 (49 UN30 3384)].



ZMU0110W010

Piston Pin Assembly Note


1. Assemble the piston pin so that connecting rod's projection for discrimination faces the opposite side of the arrow mark on the piston (rear side of the engine).
2. Apply clean engine oil to the piston pin.
3. Install the piston pin until the pin contacts the clip.
 - If the pin cannot be installed easily, heat the piston.



YMU110AAW

Piston Ring Assembly Note


1. Install the two oil control ring segments and spacer.
2. Verify that the second ring is installed with the scraper face side downward.
3. Install the top ring.



YMU110AAX


Piston, Connecting Rod Assembly Note

1. Position the end gap of each ring as indicated in the figure.



YMU110AAZ

2. Insert the piston and connecting rod into the cylinder with the arrow mark to front of the engine.



YMU110AAZ

Connecting Rod Cap Assembly Note

Caution

- Because the connecting rod bolts are pliant bolts, they cannot be reused. Use the bolts installed during inspection when assembling the connecting rod cap.

Note

- When assembling the connecting rods and connecting rod caps, it is imperative that bearing slots and tangs be located on the same side of the connecting rods.

1. Install the connecting rod bolts to the connecting rod cap by tapping the bolt with a plastic hammer.
2. Tighten the connecting rod bolts in three steps.
 - (1) Tighten to **20—25 N·m {2.0—2.6 kgf·m, 15—18 ft·lbf}**.
 - (2) Tighten to **40—45 N·m {4.0—4.6 kgf·m, 29—33 ft·lbf}**.
 - (3) Tighten **90°—120°**.


MECHANICAL

CYLINDER BLOCK ASSEMBLY(II)

B6U011010300105

1. Assemble in the order indicated in the table.

01-10



B6U224E005


1	End plate
2	Flywheel (MTX), Drive plate (ATX) (See 01-10-34 Flywheel (MTX), Drive Plate (ATX) Assembly Note)
3	Oil pump (See 01-10-34 Oil Pump Assembly Note)

4	Oil baffle (See 01-10-34 Oil Baffle Assembly Note)
5	Oil strainer (See 01-10-34 Oil Strainer Assembly Note)
6	Plate

MECHANICAL

Flywheel (MTX), Drive Plate (ATX) Assembly Note

1. Hold the flywheel (MTX) or the drive plate (ATX) using the **SST**.
2. Tighten the bolts in the order indicated in the figure in several passes.




YMU110AB2

Oil Pump Assembly Note

1. Tighten the bolts in the order indicated in the figure.

Tightening torque


8.0—12.0 N·m {82—122 kgf·cm, 71—106 in·lbf}



YMU110AB3

Oil Baffle Assembly Note


1. Tighten the nuts in two steps.
 - (1) Tighten nuts A to **5.0 N·m {51.0 kgf·cm, 44.3 in·lbf}**, then nuts B to **15.0 N·m {153 kgf·cm, 133 in·lbf}**.
 - (2) Tighten **45°** using the **SST**.



ZME2224E001

Oil Strainer Assembly Note

1. Tighten the bolts.
2. Tighten the nut in two steps.
 - (1) Tighten to **15.0 N·m {153 kgf·cm, 133 in·lbf}**.
 - (2) Tighten **45°** using the **SST**.



YMU110AB4


MECHANICAL

CYLINDER HEAD ASSEMBLY(I)

B6U011010100104

1. Assemble in the order indicated in the table.

1	Valve seal (See 01-10-35 Valve Seal Assembly Note)
2	Valve
3	Valve spring
4	Upper valve spring seat
5	Valve keeper (See 01-10-35 Valve Keeper Assembly Note)




01-10

B6U224E012

Valve Seal Assembly Note


1. Press the valve seal onto the valve guide by hand.
2. Lightly tap the **SST** using a plastic hammer.



YMU110AB6

Valve Keeper Assembly Note

1. Install the valve keeper using the **SSTs**.




YMU110AAK

MECHANICAL

CYLINDER HEAD ASSEMBLY(II)

B6U011010100105

1. Assemble in the order indicated in the table.




B6U2224E107

1	Cylinder head gasket
2	Cylinder head (See 01—10—37 Cylinder Head Assembly Note)
3	HLA

4	Water bypass tube
5	Water pump (See 01—10—37 Water Pump Assembly Note)
6	Water pump drive belt tensioner

Cylinder Head Assembly Note


1. Tighten the cylinder head bolts in the order indicated in the figure in six steps.
 - (1) Tighten to **32—38N·m {3.2—3.9kgf·m, 23—28 ft·lbf}**.
 - (2) Tighten **85°—95°**.
 - (3) Loosen **360°** (one full turn) in reverse order.
 - (4) Tighten to **32—38N·m {3.2—3.9kgf·m, 23—28 ft·lbf}**.
 - (5) Tighten **85°—95°**.
 - (6) Tighten **85°—95°**.



B6U110AB8

Water Pump Assembly Note

1. Install new bolts and tighten them in two steps.
 - (1) Tighten to **10.0 N·m {102 kgf·cm, 88.5 in·lbf}**.
 - (2) Tighten **85°—95°**.




YMU110ACD

MECHANICAL

TIMING CHAIN ASSEMBLY

B6U011012201102

1. Assemble in the order indicated in the table.



B6U2216E103

1	Rocker arm (LH)
2	Variable valve timing actuator (LH) (See 01—10—39 Variable Valve Timing Actuator Assembly Note)
3	Camshaft (LH) (See 01—10—39 Camshaft (LH) Assembly Note)
4	Camshaft cap (LH)
5	Chain guide (LH) (See 01—10—40 Chain Guide (LH, RH) Assembly Note)
6	Oil control valve (OCV)
7	Crankshaft timing sprocket
8	Timing chain (LH) (See 01—10—40 Timing Chain (LH) Assembly Note)
9	Tensioner arm (LH)
10	Chain tensioner (LH)
11	Rocker arm (RH)
12	Variable valve timing actuator (RH) (See 01—10—39 Variable Valve Timing Actuator Assembly Note)
13	Camshaft (RH) (See 01—10—40 Camshaft (RH) Assembly Note)

14	Camshaft cap (RH)
15	Chain guide (RH) (See 01—10—40 Chain Guide (LH, RH) Assembly Note)
16	Oil control valve (OCV)
17	Timing chain (RH) (See 01—10—41 Timing Chain (RH) Assembly Note)
18	Tensioner arm (RH)
19	Chain tensioner (RH)
20	CKP sensor pulse wheel (See 01—10—42 Crankshaft Position (CKP) Sensor Pulse Wheel Assembly Note)
21	Engine front cover (See 01—10—42 Engine Front Cover Assembly Note)
22	Crankshaft pulley (See 01—10—43 Crankshaft Pulley Assembly Note)
23	Auto tensioner
24	Oil pan (See 01—10—44 Oil Pan Assembly Note)
25	Camshaft oil seal housing (See 01—10—45 Camshaft Oil Seal Housing Assembly Note)

MECHANICAL


26	Water pump drive pulley (See 01-10-45 Water Pump Drive Pulley Assembly Note)
27	Water pump drive belt

28	Cylinder head cover (See 01-10-46 Cylinder Head Cover Assembly Note)
29	Oil level gauge, pipe
30	Engine hanger
31	Spark plug

01-10


Variable Valve Timing Actuator Assembly Note

1. Install the variable valve timing actuator using a new tightening bolt.
2. Secure the camshaft sprocket in a vise using the **SST**.
3. Tighten the variable valve timing actuator tightening bolt in two steps.
 - (1) Tighten to **40 N·m {4.1 kgf-m, 29.5 ft-lbf}**.
 - (2) Tighten **90°**.



Camshaft (LH) Assembly Note

1. Turn the crankshaft clockwise to position the crankshaft keyway in the **11 o'clock** position.




2. Install the camshafts (LH).
 - (1) Position the intake camshaft so that the mark is at **9 o'clock** direction.
 - (2) Position the exhaust camshaft so that the mark is at **12 o'clock** direction.

Caution

- Do not install thrust caps 1L and 6L at this time, or damage to the thrust caps may occur.

Note

- Tighten the camshafts caps at specified torque after assembling the timing chain.
- The camshaft bearing caps are numbered to make sure they are assembled in their original positions.



3. Hand tighten the camshaft (LH) caps in their original positions.

MECHANICAL

Chain Guide (LH, RH) Assembly Note

1. The chain guide should be installed to the actuator and allowed to hang freely when the bolts are installed. Do not hold the the chain guide in an upward position when the bolts are installed. The actuator causes a wear O-ring and this installation method will allow that wear to continue.


Timing Chain (LH) Assembly Note

1. Install the timing chain (LH) by aligning the colored links on the timing chain (LH) with the marks on the timing sprockets.

Caution


- Install the camshaft bearing thrust caps after installing the other bearing caps, or damage to the thrust caps may occur.

2. Align the camshaft end play using the camshaft bearing thrust caps 1L and 6L, and tighten the other bearing caps.



B6U2215E002


3. Tighten the bearing caps in the order indicated in the figure in several passes.



B6U2215W107

Camshaft (RH) Assembly Note

1. Turn the crankshaft clockwise to position the crankshaft keyway in the 3 o'clock position.



YMU110ABK

MECHANICAL

2. Install the camshafts (RH).
 - (1) Position the exhaust camshaft so that the mark is at **12 o'clock** direction.
 - (2) Position the intake camshaft so that the mark is at **3 o'clock** direction.


Caution

- Do not install thrust caps 1R and 5R at this time, or damage to the thrust caps may occur.

Note

- Tighten the camshafts caps at specified torque after assembling the timing chain.
- The camshaft bearing caps are numbered to make sure they are assembled in their original positions.

3. Hand tighten the camshaft caps (RH) in their original positions.



B6U2215E003

01-10


Timing Chain (RH) Assembly Note

1. Install the timing chain (RH) by aligning the colored links on the timing chain (RH) with the marks on the timing sprockets.

Caution


- Install the camshaft bearing thrust caps after installing the other bearing caps, or damage to the thrust caps may occur.

2. Align the camshaft end play using the camshaft bearing thrust caps 1R and 5R, and tighten the other bearing caps.



B6U2215E004

3. Tighten the bearing caps in the order indicated in the figure in several passes.
4. Install the chain tensioner and remove the retaining wire.




B6U2215W108

MECHANICAL

Crankshaft Position (CKP) Sensor Pulse Wheel Assembly Note


- Using the keyway marked 25/34Y (orange paint stripe), install the rotor with the indentation towards the front.



AMU2215W006


Engine Front Cover Assembly Note


- Apply a 6 mm {0.24 in} dot of silicon sealant as indicated in the figure (mating faces).



YMU110ABR

- Tighten the bolts and studs in the order indicated in the figure.

Hole No.	Bolt	Description
2, 5, 6, 7, 9, 12,		M8x1.25x51.8 bolt
3, 4, 14		M8x1.25x64 stud
1, 8, 13, 16		M6x1.0x20/ M8x1.25 stud
10, 11, 15,		M8x1.25x115 bolt




B6U2215W116

MECHANICAL


01-10

3. Assemble the front oil seal using part A of the **SST** [303-335 (49 UN30 3335)] and the **SST** [303-102 (49 UN01 002)] in the following order.



YMU110ABU


- (1) Apply clean engine oil to the new oil seal.
- (2) Push the oil seal slightly in by hand.
- (3) Compress the oil seal using the **SSTs**.



YMU110ACQ


Crankshaft Pulley Assembly Note

1. Using the silicone sealant, seal the keyway in the crankshaft pulley.
2. Install the crankshaft pulley using the **SST** and washer of crankshaft pulley lock bolt washer.



YMU110ABV

3. Hold the flywheel (MTX) or the drive plate (ATX) using the **SST**.
4. Tighten the crankshaft pulley lock bolt in four steps.
 - (1) Tighten to **120 N·m {12.2 kgf·m, 88.5 ft·lbf}**.
 - (2) Loosen **360°** (one full turn) in reverse order.
 - (3) Tighten **47—53 N·m {4.8—5.4 kgf·m, 35—39 ft·lbf}**.
 - (4) Tighten **85°—95°**.



YMU110ABW


MECHANICAL

Oil Pan Assembly Note

1. Apply silicone sealant to the mating faces as indicated in the figure.


Dot diameter
10 mm {0.39 in}

2. Install the oil pan with a new gasket.




YMU110ABY

3. Install the bolts and studs as indicated in the figure.



AMU2215E004


4. Align the cylinder block and the rear face of the oil pan using the straight edge.



YMU110ACS

MECHANICAL

- Tighten the bolts and studs in the order indicated in the figure.




AMU2215E005

01-10

Camshaft Oil Seal Housing Assembly Note


- Apply clean engine oil to the oil seal.
- Install the camshaft oil seal using the SSTs.



YMU110AC1

Water Pump Drive Pulley Assembly Note

- Install the new water pump pulley using the SST.




YMU110AC2

MECHANICAL


Cylinder Head Cover Assembly Note

1. Apply silicone sealant to the mating faces as indicated in the figure.
2. Install the cylinder head cover with a new gasket.



B6U2215E106

3. Tighten the bolts in the order indicated in the figure.



B6U2215E103

TECHNICAL DATA

01-50 TECHNICAL DATA

ENGINE TECHNICAL DATA 01-50-1

ENGINE TECHNICAL DATA

B6U015001001101

01-50

Item		Engine		
		AJ		
Cylinder head				
Cylinder head gasket contact surfaces distortion	(mm {in})	Maximum		0.08 {0.0031}
Valve and valve guide				
Valve stem diameter	(mm {in})	Standard	IN	5.975—5.995 {0.2352—0.2360}
			EX	5.950—5.970 {0.2343—0.2350}
Valve stem to guide clearance	(mm {in})	Standard	IN	0.020—0.069 {0.0008—0.0027}
			EX	0.045—0.094 {0.0018—0.0037}
Valve guide projection height	(mm {in})	Standard	IN	13.4—14.2 {0.528—0.559}
			EX	13.4—14.2 {0.528—0.559}
Valve seat				
Valve seat contact width	(mm {in})	Standard	IN	1.1—1.4 {0.043—0.055}
			EX	1.4—1.7 {0.056—0.066}
Valve seat angle			(°) IN	45
			EX	45
Valve spring				
Pressing force at valve spring height H	(mm {in})	680 N {69.3 kgf, 152 lbf}		30.19 {1.189}
Off-square	(mm {in})	Maximum		1% {0.468 {0.00184}}
Camshaft				
Cam lobe height	(mm {in})	Standard	IN	4.79 {0.189}
			EX	4.79 {0.189}
Journal diameter	(mm {in})	Standard		26.936—26.962 {1.0604—1.0615}
Journal oil clearance	(mm {in})	Standard		0.025—0.076 {0.0010—0.0029}
		Maximum		0.121 {0.00476}
End play	(mm {in})	Standard		0.025—0.165 {0.0010—0.0064}
		Maximum		0.190 {0.00748}
HLA				
HLA bore diameter	(mm {in})	Standard		16.018—16.057 {0.63063—0.63216}
HLA diameter	(mm {in})	Standard		15.988—16.000 {0.62945—0.62992}
HLA-to-HLA bore oil clearance	(mm {in})	Standard		0.018—0.069 {0.0008—0.0027}
		Maximum		0.16 {0.0063}
Cylinder block				
Distortion	(mm {in})	Maximum		0.08 {0.0031}
Cylinder bore diameter [Measure the cylinder bore at 50 mm {2.0 in} below the top surface]	(mm {in})	Standard		89.000—89.030 {3.5039—3.5051}
Taper	(mm {in})	Maximum		0.020 {0.00079}
Off-round	(mm {in})	Maximum		0.020 {0.00079}
Piston				
Piston diameter [Measured at 90° to pin bore axis and 42.6 mm{1.68 in} below the top of piston]	(mm {in})	Standard		88.990—89.030 {3.5036—3.5051}
Piston-to-cylinder clearance	(mm {in})	Standard		0.012—0.022 {0.0004—0.0008}

TECHNICAL DATA

Item			Engine	
			AJ	
Piston ring				
Piston ring-to-ring groove clearance	(mm {in})	Standard	Top	0.040—0.075 {0.0016—0.0029}
			Second	0.040—0.085 {0.0016—0.0033}
	Maximum			0.10 {0.0039}
End gap (measured in cylinder)	(mm {in})	Standard	Top	0.10—0.25 {0.004—0.009}
			Second	0.27—0.42 {0.011—0.016}
			Oil (rail)	0.15—0.65 {0.006—0.025}
	Maximum	Top	0.50 {0.019}	
		Second	0.65 {0.025}	
		Oil (rail)	0.90 {0.035}	
Piston pin				
Piston pin diameter	(mm {in})	Standard	21.011—21.013 {0.82721—0.82728}	
Piston pin bore diameter	(mm {in})	Standard	21.008—21.012 {0.82709—0.82724}	
Connecting rod-to-piston pin clearance	(mm {in})	Standard	0.004—0.020 {0.00016—0.00078}	
		Maximum	0.035 {0.0013}	
Piston pin bore-to-piston pin clearance	(mm {in})	Standard	-0.005—0.001 {-0.00019—0.00003}	
Connecting rod and connecting rod bearing				
Length (center to center)	(mm {in})	Standard	138.06—138.14 {5.4355—5.4385}	
Bending	(mm {in})	Maximum	0.038 {0.0014}/25 {0.98}	
Distortion	(mm {in})	Maximum	0.050 {0.0019}/25 {0.98}	
Connecting rod small end inner diameter	(mm {in})	Standard	21.017—21.031 {0.82744—0.82799}	
Connecting rod side clearance	(mm {in})	Standard	0.10—0.30 {0.004—0.011}	
		Maximum	0.35 {0.013}	
Connecting rod bearing size	(mm {in})	Standard	1.500—1.506 {0.0591—0.0593}	
		0.02 {0.0008} undersize	1.510—1.516 {0.0595—0.0596}	
		0.05 {0.0020} undersize	1.525—1.531 {0.0601—0.0602}	
		0.25 {0.0100} undersize	1.625—1.631 {0.0640—0.0642}	
Connecting rod bearing oil clearance	(mm {in})	Standard	0.028—0.066 {0.0012—0.0025}	
Crankshaft				
Crankshaft runout	(mm {in})	Maximum	0.05 {0.0019}	
Main journal diameter	(mm {in})	Standard	62.968—62.992 {2.4791—2.4799}	
		0.25 {0.01} undersize	62.718—62.742 {2.4693—2.4701}	
Main journal oil clearance	(mm {in})	Standard	0.025—0.045 {0.0010—0.0017}	
		Maximum	0.050 {0.0019}	
Main bearing size	(mm {in})	Standard	Grade 1	Upper No.1,2,3,4; Lower No.1,2,3: 2.494—2.500 {0.09819—0.09842} Lower No.4: 2.492—2.498 {0.09812—0.09834}
			Grade 2	Upper No.1,2,3,4; Lower No.1,2,3: 2.498—2.504 {0.09835—0.09858} Lower No.4: 2.496—2.502 {0.09827—0.09850}
			Grade 3	Upper No.1,2,3,4; Lower No.1,2,3: 2.502—2.508 {0.09851—0.09873} Lower No.4: 2.500—2.5006 {0.09843—0.09844}
		0.25 {0.01} undersize	Upper No.1,2,3,4; Lower No.1,2,3: 2.623—2.629 {0.10327—0.10350} Lower No.4: 2.621—2.627 {0.10319—0.10342}	

TECHNICAL DATA

Item		Engine	
		AJ	
Crank pin journal diameter	(mm {in})	Standard	49.970—49.990 {1.9674—1.9681}
		0.02 {0.0008} undersize	49.950—49.970 {1.9666—1.9673}
		0.05 {0.0020} undersize	49.920—49.940 {1.9654—1.9661}
		0.25 {0.0100} undersize	49.720—49.740 {1.9575—1.9582}
Crankshaft end play	(mm {in})	Standard	0.110—0.232 {0.00434—0.00913}
Camshaft oil seal			
Pushing distance of the camshaft oil seal [from the edge of the oil seal housing]	(mm {in})		2.5—3.0 {0.10—0.11}
Front oil seal			
Pushing distance of the front oil seal [from the edge of the engine front cover]	(mm {in})		0—1.0 {0—0.04}
Rear oil seal			
Pushing distance of the rear oil seal [from the edge of the cylinder block]	(mm {in})		0—2.0 {0—0.08}
Oil control valve (OCV)			
Resistance	(ohm)		7.05—7.95

01-50

SERVICE TOOLS

01-60 SERVICE TOOLS

ENGINE SST01-60-1

ENGINE SST

1: Mazda SST number
2: Global SST number


B6U016001001101













01-60

Example







1:49 UN30 3009
2:303-009

Crankshaft damper remover



<p>1.49 L010 1A1 2. -</p> <p>Engine hanger set</p> 	<p>1.49 0107 680A 2. -</p> <p>Engine stand</p> 	<p>1.49 UN30 3009 2.303-009</p> <p>Crankshaft damper remover</p> 
<p>1.49 UN30 3457 2.303-457</p> <p>Shaft protector</p> 	<p>1.49 UN30 3456 2.303-456</p> <p>Water pump pulley plate</p> 	<p>1.49 T034 204 2. -</p> <p>Attachment (Part of 49 T034 2A1)</p> 
<p>1.49 E011 1A0 2. -</p> <p>Ring gear brake set</p> 	<p>1.49 0636 100B 2. -</p> <p>Valve spring lifter arm</p> 	<p>1.49 B012 0A2 2. -</p> <p>Pivot</p> 
<p>1.49 S120 170 2. -</p> <p>Valve seal remover</p> 	<p>1.49 T011 001 2. -</p> <p>Piston pin installer</p> 	<p>1.49 G030 797 2. -</p> <p>Handle (Part of 49 G030 795)</p> 
<p>1.49 UN01 070 2.303-178</p> <p>Crankshaft seal installer</p> 	<p>1.49 UN30 3384 2.303-384</p> <p>Rear crankshaft adapter bolts</p> 	<p>1.49 D032 316 2. -</p> <p>Protractor</p> 

SERVICE TOOLS

<p>1.49 G030 043 2. –</p> <p>Guide (Part of 49 G030 040)</p> 	<p>1.49 UN30 3335 2.303-335</p> <p>Crankshaft seal installer/aligner</p> 	<p>1.49 UN01 002 2.303-102</p> <p>Crankshaft damper replacer</p> 
<p>1.49 UN21 1185 2.211-185</p> <p>Pump pulley replacer</p> 	<p>1.49 UN30 3464 2.303-464</p> <p>Camshaft seal replacer</p> 	<p>1.49 UN30 3463 2.303-463</p> <p>Camshaft seal protector</p> 
<p>1.49 B012 015 2. –</p> <p>Valve guide installer</p> 	<p>1.49 L012 0A0B 2. –</p> <p>Valve seal and valve guide installer set</p> 	<p>1.49 1352 060 2. –</p> <p>Ring gear brake</p> 