



# CX5 LED DRL Installation Instruction

## Installation


### 1. Remove the stock fog lamp cover




### 2. Install LED DRL



### 3. Wiring



### 4. Wire harness



White wire : head lamp signal

Blue wire : running light signal

Black wire : ground

Red wire : ACC fuse


5. Install ACC fuse, and negative  
 5-1. Open the fuse box in engine room.  
 Remove 10A red fuse as below mark  
 Connect 10A fuse  
 Connect ACC (red wire) to the fuse position




5-2. Install the negative  
 Connect black wire (negative) as below mark



6. Connect head light and running light



a. Running light (brown/white wire) is positive, using clip to connect the wires.  
 b. Head light (red/green wire) is positive, using clip to connect the wires.



Enjoy your LED DRL