



CN101 24P CONNECTOR

1.	NC	
2.	NC	
3.	NC	
4.	NC	
5.	NC	
6.	NC	
7.	NC	
8.	NC	
9.	NC	
10.	NC	
11.	NC	
12.	Control Ill Signal	(CONT-ILL)
13.	NC	
14.	Monitor Serial Input	(SI01)
15.	Shield GND	(D.GND)
16.	Monitor Serial Output	(SI02)
17.	Video GND	(VGND)
18.	Composit Sync	(SYNC)
19.	NC	
20.	Video Signal (Blue)	(B)
21.	Video GND	(VGND)
22.	Video Signal (Green)	(G)
23.	NC	
24.	Video Signal (Red)	(R)



CN102 16P CONNECTOR

1.	GND	(GND)
2.	Power Supply	(+B)
3.	NC	
4.	Power Supply	(ACC)
5.	PR Speaker Input (-)	(PRF SP IN-)
6.	NC	(ILL-)
7.	PR Speaker Input (+)	(PRF SP IN+)
8.	Speed Signal	(SPEED)
9.	PR Speaker Output (-)	(PRF SP OUT-)
10.	Side Brake	(PKB)
11.	PR Speaker Output (+)	(PRF SP OUT+)
12.	Revers	(REV)
13.	Front Speaker Output (-)	(F SP OUT-)
14.	Front Speaker Output (+)	(F SP OUT+)
15.	Front Speaker Input (-)	(F SP IN-)
16.	Front Speaker Input (+)	(F SP IN+)



CN801 8P CONNECTOR

1.	GND	(GND)
2.	Power Supply	(+B)
3.	Reset	(RESET)
4.	Power	(+B SW)
5.	Serial Input	(RX-DATA)
6.	NC	
7.	Serial Output	(TX-DATA)
8.	NC	